




Wood Repair PLUS+ Kit

For Knot Filler application

Complete wood repair kit for Knot Filler application. With the Wood Repair PLUS+ Kit you have all necessary tools at hand to get started and make perfect Knot Filler repairs. The PLUS+ kit is very suitable for window-and floor installers, carpenters, maintenance people etc.

The Wood Repair PLUS+ Kit includes a BCD180 Knot Filler gun, two Knot Filler Compact bags (8 sticks with a length of 150mm per bag) and different tools.




1. Choose a color



2. Fill



3. Cool



4. Cut



5. Sand



6. Surface treat

Instructions:

- 1) Put a Knot Filler stick in the pre-heated gun (170 °C).
- 2) "Shoot" the Knot Filler into the knot/defect.
- 3) Quickly place a cooling brick on the warm Knot Filler repair. This presses the Knot Filler into the defect/repair and cools it down.
- 4) Use the chisel to cut off excess Knot Filler.
- 5) Sand the repair and apply surface treatment.
- 6) When the Knot Filler repair has been sanded you can after treat it with any surface treatment, i.e. oil, lacquer, stain, paint etc.

Content:



BCD 180 Knot Filler gun

Basic 80W gun for Ø12mm sticks and changeable nozzle. Very suitable for carpenters, service people, handy men, DIY'ers etc.



Chisel

For removing excess Knot Filler. 50mm chisel with sharp steel blade and beech handle.



Knot Filler Compact Bag Mix 1

Knot Filler compact bag with 8 sticks in four colors: Knot, Pine, Oak, Mahogany.

8 Sticks, 150mm, Ø12mm.



Cooling bricks

Two cooling bricks for pressing the Knot Filler into the repair/defect and cooling off the warm Knot Filler. 50x50x30 mm, Aluminum.



Knot Filler Compact Bag Mix 2

Knot Filler compact bag with 8 sticks in four colors: Ash, Beech, Walnut, Black.

8 sticks, 150mm, Ø12mm.



Knot Filler Saver

For changing colors. Form new sticks to use for later woodwork. Silicone, 60x40x35mm, Ø12mm.